



LAVI SYSTEMS, INC.

NOMENCLATURE	APP	NSN	LSI PART NO.
TANK UNIT ASSY	A-3	6680-00-670-5133	T-3300-A3
TRANSMITTER, LIQUID QTY	A-4	6680-00-717-1757	T-6300-A4
TRANSMITTER, LIQUID QTY	A-6	6680-00-573-8138	T-415-A6
TRANSMITTER, LIQUID QTY	A-6	6680-00-573-8137	T-418-A6
TANK UNIT	A-6	6680-00-083-6352	T-425-A6
TANK UNIT	A-6	6680-00-083-6354	T-426-A6
THERMO RESISTOR	B-52	5905-01-167-8648	S-246-B52
SENSOR, TEMPERATURE	C-5A	1660-00-927-2013	S-9211-C5A
THERMOSTAT, PNEUMATIC	C-130	1660-00-649-7487	9332604-10
INDICATOR, TEMPERATURE	C-130	6685-00-183-0351	9440400
COMPENSATOR, LIQUID QTY	C-130	6680-01-067-4552	1089100
INDICATOR, TORQUEMETER	CH-47	6620-01-179-9737	9233600
INDICATOR, FUEL QTY	CH-47	6695-00-045-4522	I-1400-CH47
SENSOR, TEMPERATURE	C-141	6685-00-021-9923	S-7920-C141
SENSOR, TEMPERATURE	C-141	6685-00-267-0938	S-7921-C141
SENSOR, TEMPERATURE	C-141	6685-00-759-2293	S-7922-C141
SENSOR, TEMP CONTROL	C-141	6685-00-260-9374	T-7933-C141



LAVI SYSTEMS, INC.

TANK UNIT, INTERMED WING	F-4	6680-00-946-9998	T-300-F4
TANK UNIT, OUTBOARD WING	F-4	6680-00-911-4290	T-301-F4
TANK UNIT, INBOARD WING	F-4	6680-00-911-4291	T-302-F4
TANK UNIT, NO 3 FUSELAGE	F-4	6680-00-911-4298	T-304-F4
TANK UNIT, NO 1 FUSE UPPER	F-4	6680-00-945-1205	T & SL-305-F4
TANK UNIT, NO. 1 FUSE, LOWER	F-4	6680-00-953-1815	T & C-306-F4
TANK UNIT, NO. 2 FUSE	F-4	6680-00-907-5703	T -307 -F4
TANK UNIT, NO. 4 FUSE	F-4	6680-00-911-4295	T -308 -F4
TANK UNIT, NO. 5 FUSE	F-4	6680-00-919-2702	T-309-F4
TANK UNIT, NO. 2 FUSE	F-4	6680-00-220-2843	T & SL-315-F4
TRANSMITTER, WING SWITCH	F-14	6610-00-029-9407	9127800
TRANSMITTER, LIQUID	F-15	6680-00-290-6479	9181200
CONTROL, FAIL SAFE	F-15	1660-01-098-2753	9241778-10
AMPLIFIER, INTERCOM	F-16	1680-01-053-9287	9130500
INDICATOR, NOZZLE POSITION	F-16	6620-00-189-9444	9130900
FUEL PROBE	F-16	6680-01-058-3531	T-100-F16
FUEL PROBE	F-16	6680-01-058-1436	T-101-F16
FUEL PROBE	F-16	6680-01-058-3530	T-102-F16



LAVI SYSTEMS, INC.

TRANSMITTER, LIQUID QTY	F-16	6680-01-072-2798	0887700
FLIGHT CONTROL PANEL	F-16	6615-01-127-3160	16C0605-825
TRANSMITTER, LIQUID	F-104	6680-00-889-7168	T-3201-F104
TRANSMITTER, LIQUID	F-111	6680-00-945-4967	T-600-F111
SENSOR, TEMP, ELECT COOLING	F-111	5905-01-083-1917	S-2100-F111
SENSOR, TEMPERATURE	F-111	5905-00-928-5059	S-2107-F111
SENSOR, TEMP, ELECT COOLING	F-111	5905-00-450-2515	S-2200-F111
SENSOR, TEMPERATURE	F-111	5905-00-928-7637	S-2700-F111
TEMPERATURE SENSOR ASSY	KC-135	6685-01-192-0486	SM-C-978769
INDICATOR, TEMPERATURE	KC-135	6685-00-514-5327	9131800
TANK UNIT, NO. 1 & NO. 4 MAIN	KC-135	6680-00-526-7250	T-4911-KC135
TANK UNIT, NO. 1 & NO. 4 RES	KC-135	6680-00-526-7263	9339500
TANK UNIT, NO. 1 & NO. 4 RES	KC-135	6680-00-526-8060	9339600
TANK UNIT, NO. 1 & NO. 4 RES	KC-135	6680-00-526-8061	9339700
COMPARATOR TANK UNIT, NO. 2 & NO. 3 MAIN	KC-135	6680-00-526-4380	9339900
COMPARATOR TANK UNIT,	KC-135	6680-00-526-7237	9340000



LAVI SYSTEMS, INC.

NO. 1 & NO. 4 RES

TANK UNIT, FORWARD BODY	KC-135	6680-00-526-7173	9340200
COMP UNIT, FORWARD BODY	KC-135	6680-00-551-3406	9340900
COMPENSATOR, LIQUID QTY	KC-135	6680-01-036-9373	9858100
COMPENSATOR, LIQUID QTY	KC-135	6680-00-526-7407	0282800
TRANSMITTER, LIQUID QTY	KC-135	6680-00-526-7240	0282900
COMPENSATOR, LIQUID QTY	KC-135	6680-00-526-8066	0283100
TANK UNIT, FWD FUSELAGE	T-38/F5	6680-00-071-3983	T-2400-T38
TANK UNIT, FWD CTR FUSELAGE TOP	T-38/F5	6680-00-800-1586	T-2401-T38
TANK UNIT, AFT DORSAL	T-38/F5	6680-00-800-1587	T-2402-T38
TANK UNIT, FWD DORSAL	T-38/F5	6680-00-800-1588	T-2403-T38
TANK UNIT, CTR DORSAL	T-38/F5	6680-00-800-4505	T-2404-T38
TANK UNIT, AFT	T-38/F5	6680-00-800-4510	T-2405-T38
TANK UNIT, AFT CTR FUSELAGE BOTTOM	T-38/F5	6680-00-800-4510	T-2405-T38
TANK UNIT, AFT FUSELAGE	T-38/F5	6680-00-854-7503	T-2406-T38
TRANSMITTER, LIQUID	UH-1	6680-00-758-2816	T-1100-UH1
INDICATOR DAMPER	UH-60	1615-01-394-3898	9341101-1



LAVI SYSTEMS, INC.

PANEL, CAUTION ADVISORY	UH-60	1680-01-214-0193	9544600
PANEL, CAUTION ADVISORY	UH-60	1680-01-225-5629	9544600-20
PANEL, CAUTION ADVISORY	UH-60	1680-01-471-7013	9544600-40
PANEL, CAUTION ADVISORY	UH-60	1680-37-A01-6630	9544600-60
MASTER ALARM PANEL	UH-60	6225-01-455-3846	9753500-107
SENSOR, TEMPERATURE ASSEMBLY	VARIOUS	6685-01-192-0486	SM-C-978769
GAGE, TEMPERATURE	SHIPS	6620-00-105-3312	S-2300-N
SENSOR, TEMPERATURE	CIWS	6685-01-188-7743	S-1500-CIWS
HOUSING, LAMP ASSY	CARRIER LIGHTS	1280-00-475-7386	2950-378
INDICATOR, LIQ SIGHT LEVEL	VARIOUS	6680-00-060-4646	9024800

REPLACEMENT PARTS

DASHPOT	UH-60	5342-01-395-7955	9341102
DASHPOT	UH-60	5342-01-395-7954	9341104
DASHPOT	UH-60	5342-01-395-7953	9341105
RING, EXTERNALLY THREADED	UH-60	<u>5365-01-390-7127</u>	9341107
DASHPOT	UH-60	5342-01-395-7952	9341109



LAVI SYSTEMS, INC.

SCRAPER	UH-60	<u>3120-01-395-6027</u>	9341113
DASHPOT	UH-60	5342-01-395-7956	9341114
RETAINER, PACKING	UH-60	5330-01-394-8494	9341115
RETAINER, PACKING	UH-60	5330-01-394-7851	9341116
WASHER, FLAT	UH-60	5310-01-394-6374	9341117
WASHER, FLAT	UH-60	5310-01-394-6378	9341118
HANDLE, MANUAL	UH-60	5430-01-392-1572	9341119
RETAINER, PACKING	UH-60	5330-01-394-7852	9341120
LENS, RETAINER	UH-60	1680-01-147-3671	9544618
FLEX CIRCUIT, W1	UH-60	5905-01-373-1303	9544634
FLEX CIRCUIT, W2	UH-60	5905-01-373-1304	9544635
FLEX CIRCUIT, W3	UH-60	5998-01-372-2173	9544636
FLEX CIRCUIT, W4	UH-60	5905-01-373-1305	9544637
FLEX CIRCUIT, W5	UH-60	5995-01-467-2206	9544638
FLEX CIRCUIT, W6	UH-60	5905-01-373-1307	9544639
FLEX CIRCUIT, W6	UH-60	5905-01-373-1308	9544640
CABLE ASSEMBLY, PRINTED	UH-60	5995-01-467-2213	9544648



LAVI SYSTEMS, INC.

CIRCUIT CARD ASSY A1	UH-60	5999-01-113-8236	9544649
CIRCUIT CARD ASSY A2	UH-60	5998-01-113-8235	9544650
CIRCUIT CARD ASSY A3	UH-60	5998-01-372-2173	9544651
CIRCUIT CARD ASSY A4	UH-60	5998-01-459-2144	9544652
CIRCUIT CARD ASSY A5	UH-60	5998-01-330-5099	9544653
CONTACT, LAMP	UH-60	6610-00-029-9407	9544673